



The first steps:

If you would like to establish a *Bluetooth*® connection for the first time, you must activate the *Bluetooth*® function in your mobile telephone and start the search for *Bluetooth*® devices. Search for a device with the description „AD 9060“. If several devices have been found, please select and connected the AD 9060 and enter the **PIN number` 1234`** . The subsequent functions are described in the operating manual.



Voice commands which are valid for all menus:

Cancel

Ends the voice control function.

Help

By saying Help you can hear the commands, which are available in each submenu.

Back

One step back.

Head menu

The main menu is open.

The most important voice commands:

Hauptmenü

Dial Joe Bloggs

Will not be displayed in the head menu.

Will not be displayed in the head menu. Direct call of a phonebook entry.

If you have saved more than one number for one person, you can dial directly via the category, e.g.

„Dial Joe Bloggs home“

It is important to match the announced name exactly with the phone book entry.

Dial number

- Digits (0..9)
- Playback
- Delete all
- Delete last
- Dial
- Delete group

Special symbols like +, * and # can be actuated in the same way as the *Pause* function (space character) e. g. for mailbox functions.

Phone book

- Select entry <digit>
- Playback
- Play list
- Select Joe Bloggs
- Dial
- Fast search
- Get details
 - Dial home
 - Dial mobile
 - Dial office
 - Dial general
 - Dial SIM
 - Voice Tag
 - Store
 - Number
- Next
- Previous
- Next Page
- Previous Page

Redial

Here, you can re-dial the telephone number which was most recently dialled with the hands-free car kit.

Call lists

- Dialed calls
- Received calls
- Missed calls

In these menu items the following commands are available to you:

- Select entry <digit>
- Number
- Playback
- Dial
- Next
- Previous
- Next page
- Previous page

Head menu

Messages

- All messages
- New messages

In these menu items the following commands are available to you:

- Select entry <digit>
- Playback
- Dial
- Read
- Next
- Previous
- Next page
- Previous page

Read new message

Will not be displayed in the head menu.

With this voice prompt you can directly reach a new message.

- Bluetooth
- Phone list
- Clear list
- Pin code
 - Default
 - User
 - Accept
- Auto connect on / off
- Playback

Settings

- Voice dial
- Advanced help on / off
- Audio feedback an / aus
- Speaker adaptation
- Description




- Audio
- DSP
- Enable / Disable DSP
- Phone DSP
- Device DSP
- Echo suppression
- Playback
- Ringtones
- Volume
- Speech
- Ringtone
- More
- Less
- Maximum
- Minimum
- Accept
- Mute delay
- Playback
- Select entry <digit>

- Display
- Sleep mode
- Enable / Disable
- 15 seconds
- 30 seconds
- 60 seconds
- Illumination
- More
- Less
- Maximum
- Minimum
- Accept
- Day/Night mode
- Colour theme
- Calibration
- Playback

- Device
- Call answering
- Manual
- Automatic
- Voice
- Language
- Phone book options
 - Invert names on / off
 - Sync phone book
- System
- Version Info
- Software update
- Factory setting
- Yes
- No



Handling via touch screen:

All displayed commands can also be operated intuitively via touch screen and are self explaining. Except more voice tags. **Read new message** and **Dial Joe Bloggs**. The operation can be carried out via possibly existing arrow keys. With the **red** symbols   you can cancel an action or go a step back. With the **green** symbol  you can confirm actions. In certain menus speech support is available. You can activate the audio feedback by touching the field Audio feedback in the menu Voice dial.

Copyright © 01/2009 **BURY GmbH & Co. KG** hotline@bury.com www.bury.com

For the purpose of technical progress BURY Technologies reserves the right to change the information mentioned in this document without further announcement. The scope of the functions described for all BURY products may vary according to your mobile phone, your network service provider and the date of your software. Subject to alterations and errors excepted.